

INSTRUCTION MANUAL

& REFERENCE GUIDE



INTRODUCTION

Serpent developed the S100 LTR model car for demanding racers in the highly competitive electric 1/10th scale pan car market, which like all our previous cars, has been designed to win straight from the box.

Featuring a number of very effective features such as a fully adjustable front end, machined aluminium rear pod, side-links combined with ball-link tube-system to control chassis roll and grip, top-mounted shockabsorber, quick and easy tweak adjustment and top quality materials throughout, the S100 LTR should see you in the winners circle in no time. In fact everything associated with this car is of the highest quality, from the packaging and supplied manuals, right through to the product and race support.

For latest information about S100 LTR check on: www.serpent.com/410052

Enjoy racing!

Team Serpent

INSTRUCTIONS

Serpent's long tradition of excellence extends to the instruction manuals, and this instruction manual is no exception. The easy-to-follow layout is richly illustrated with 3D-rendered full-color images to make your building experience quick and easy. Following the instructions will result in a well-built, high-performance race-car that will soon be able to unleash its full potential at the racetrack.

INSTRUCTIONS, HOW TO USE

The kit includes bags, with bagnumbers, which refer to the same step in the manual. Open only the indicated bag(s) per step and finish that part of the assembly. Remaining parts will be needed lateron in the assembly process.

SETUP

In certain assembly steps you need to make basic adjustments, which will give you a good initial setup for your Serpent S100 LTR. Fine-tuning the initial setup is an essential part of building a high-performance racecar like your S100 LTR.

EXPLODED VIEWS AND PARTS LIST

The exploded views and parts lists for the Serpent S100 LTR are presented in the Reference Guide section in the back of this manual. The exploded views show all the parts of a particular assembly step along with the Serpent part number. The parts lists indicate the part number andname of each part for easy reference when ordering.

CUSTOMER SERVICE

Serpent has made a strong effort to make this manual as complete and clear as possible. Additional info may be published in our website: www.serpent.com or you may ask your dealer or the Serpent distributor for advice, or email Serpent direct: info@serpent.com



The Serpent Facebook, Twitter and Youtube pages give additional means of support and communications.

SAFETY

Read and take note of the 'Read this First section' before proceeding to assemble the car-kit. This car-kit is intended for persons aged 16 or older.

Read this first!

- This is a highly technical hobby product, intended to be used in a safe racing environment. This car is capable of speeds in excess of 80 km/h or 50mph. Please follow these guidelines when building and operating this model.
- Parental guidance is required when the builder/user of this car is under 16.
- Follow the building instructions. If in doubt, contact your dealer or importer.
- Be sure to use the proper tools when assembling the car. Always exercise caution when using electric tools, knives and other sharp objects.
- Be careful when using liquids like lubrication oil, fuel or glue. Do not swallow.
- ${\mbox{-}}$ Follow the manufacturer's instruction in case you experience irritation after using the product.
- Be careful when operating the car. Stay away from any rotating parts such as wheels, gears and transmission. Stay away from motor, engine and exhaust pipe system or speedo during and immediately after use, as these parts may be very hot. We advise to use protective hand cloves.
- Only operate this car in a safe environment, like a special racing track or a closed parking lot. Avoid using this car on public roads, crowded places or near infants.
- Before operating this car, always check the mechanical status of the car. Also check that the transmitter and receiver frequencies correspond and are not used by any other racer at the same time. Check that the batteries of the transmitter and receiver- are fully charged.
- After use, always check all the mechanics of the car. We advise to clean the car immediately after use, and inspect the parts for wear or fractures.

Replace when necessary. Do not use water, methanol, thinner or other solvents to clean the car.

- Empty the fuel tank (depending on model) if needed and disconnect the

receiver battery.

- Store the car in a dry and heated place to avoid corrosion of metal parts.
- Avoid using this car in wet conditions as the water will cause corrosion on

the metal parts and bearings and these parts will cease to function properly.

If driven in the wet, ensure that all the electric equipment is waterproofed


and after use, that all moving parts are dried immediately.

CONTENTS

FRONT ASSEMBLY	4
REAR ASSEMBLY	7
BALL DIFF ASSEMBLY	12
SERVO AND BATTERY ASSEMBLY	13
SHOCK ASSEMBLY	18
FINAL ASSEMBLY	20
REFF GUIDE	25

USING THE MANUAL

Each step contains a variety of numbers, lines, and symbols. The numbers represent the order in which the parts should be assembled. The lines and symbols are described below.




ASSEMBLY INSTRUCTIONS

KIT




FRONT ASSEMBLY




STEP 3

Bag










Bag 2





6

Page

Note orientation of the king pin Nylock Nut МЗ insert. M3x6


Default ackermann position in the steering block lever.

King pin angle adjustable from 0 to 4 degrees. 00 10 **2**º 30 40 Default setup


Steering block King pin inserts









REAR ASSEMBLY

















12


Bag 4






Page


A) OUTSIDE SIDE SPRING CONFIGURATION (DEFAULT)




B) INSIDE SIDE SPRING CONFIGURATION





14















STEP

18

BALL DIFF ASSEMBLY





Rear ride height inserts

The rear ride height is adjustable in steps of 0.5mm increments using different rear axle bearing adapters. The ride height decreases if the axle is placed higher.

0\0 0\05 0\10 0\15 0\20 0\25 0\30 0\35 0\40





SERVO AND BATTERY ASSEMBLY

NOTE:

19A


Bag

Page


Serpent S100 LTR is designed to create two different battery/servo configurations:

- A) Detail view shorty battery and laydown servo configuration (default)
- B) Detail view standard battery and standing servo configuration.


Below you can see a detail view of both configurations. Please follow the right steps for the choosen configuration: A or B



A) Shorty battery and laydown servo configuration (default)



sтер **20А**



B) Standard battery and standing servo configuration.

STEP 19B









STEP 20B












STEP 21B











Page














STEP **25**

Bag 7


SHOCK ASSEMBLY





26

Bag 8












STEP **29**






FINAL ASSEMBLY














REFERENCE GUIDE






FRONT ASSEMBLY




BALL DIFF ASSEMBLY





Э

REAR ASSEMBLY




SHOCK ABSORBER ASSEMBLY






STEERING ASSEMBLY A



STEERING ASSEMBLY B






Please click here to check all the Optional Parts



FINAL ASSEMBLY



Please click here to check all the **Optional Parts**

TEAM SERPENT NETWORK

S100 LTR SPARE PARTS









S100 LTR OPTIONAL PARTS









SERPENT TOOLS









SERPENT MERCHANDISING









WEBSITE AND BLOG







SOCIAL MEDIA





















